Application Note - AN 100
Access to Planevision Systems
Internet Customer Area

Customized documentation for PlaneTRack devices is accessible via a closed internet customer web area.

Here is how to access: the Customer Area:

1. **Retrieve your user login and password from the frontpage of the printed Operating Manual or the nameplate of your PlaneTRack device.**





2. Enter the URL into your browser address line:

3. Enter the login (6 digits without dot) and password into the dialog fields and press ENTER. The login must not necessarily be the serial number of your device. Several equal devices may be clustered under a single master login.



Now you will see a directory listing with all files available for your devices. You can retrieve files by just clicking on list entry.



Version: 1.1
Revision date: 2019-02-18
Changes: Login page and procedure revised